

Index

A

abort changes	3-37
Advanced Configuration	3-31
Advanced PIO Mode	3-14
AGP	2-1
audio controller	3-19

B

BIOS bottom command lines	3-3
BIOS level	
advanced	3-2
BIOS levels	
Level 2	3-2
BIOS main menu	3-2
BIOS version	3-8
Boot Options	3-22
boot sequence	3-22

C

cache scheme	3-33
CD-ROM Drive DMA Mode	3-14
Celeron	2-1
installation	2-17
connecting components	1-4, 1-8
fax/modem	1-11
keyboard	1-4
monitor	1-5
mouse	1-6
multimedia	1-9
network connection	1-10
printer	1-7

D

Date	3-25
Date and Time	3-24
Disk Drives	3-9
diskette drive configuration	3-9
display adapter	3-23
DMA Transfer Mode	3-14
DMI BIOS version	3-8
drive control settings	3-30
drive cylinder	3-12
drive head	3-13
drive sector	3-13
drive size	3-13
drive type	3-12

E

ECP DMA	3-17
Enter setup	3-2
exit Setup	3-38

F

fast boot	3-23
floppy disk controller	3-18
floppy drive A	3-5
floppy drive B	3-5

H

hard disk 32-bit access	3-14
Hard Disk Block Mode	3-13
hard disk drive configuration	3-11
HDD size>504MB	3-13

Hardware Monitoring function	2-12
HDD size>504MB	3-12

I

I/O ports	2-1
IDE 1	
master	3-6
slave	3-6
IDE 2	
master	3-6
slave	3-6
IDE configuration	3-11
IDE controller	3-18
IRQ sharing	3-35
IRQ12	3-19

L

L1 cache	3-5, 3-32
L2 cache	3-33
LDCM	2-12
loading default settings	3-37
LS-120 configuration	3-10

M

main board ID	3-8
main board serial number	3-8
Memory at 15MB-16MB Reserved For	3-33
memory test	3-24
Memory/Cache Configuration	3-32
MMX	2-1
Modem Ring-In	2-12
modem ring indicator	3-22

N

num lock	3-24
----------	------

O

Onboard Device Settings	3-18
Onboard Peripherals	3-15

P

parallel port	
address	3-16
configuration	3-16
IRQ	3-16
parallel port operation modes	3-17
PCI IRQ	3-34
PCI slots	3-35
Pentium II	2-1, 2-12
installation	2-13
removing	2-12
Plug and Play	3-36
PnP	3-36
PnP/PCI Configuration	3-34
preinstallation	1-1
power	3-21
Power Management	3-20
power management mode	3-20
sleep mode	3-21
system sleep timer	3-21
power management modes	3-20
IDE hdd standby mode	3-20
Power On password	3-29
processor	3-5
processor speed	3-5
Product Information	3-7
Product Name	3-8

R

resetting IRQ assignments	3-36
RTC	
Time	3-25

S

serial port	
address	3-15
configuration	3-15
IRQ	3-16
Setup password	
bypassing	3-29
changing	3-28
removing	3-28
setting	3-26
silent boot	3-23
SMART	3-12
special features	2-1
supported operating systems	2-2
system board	
board layout	2-4
system features	1-2
front panel	1-2
rear panel	1-3
System Information	3-4
system power off	1-12
system power on	1-12
System Security Setup	3-25
System Security Setup	3-26
system serial number	3-8
system total memory	3-6

T

troubleshooting	1-13
error messages	1-14

U

USB	2-12
USB controller	3-19
USB legacy mode	3-19

V

VGA palette snooping	3-35
video feature	2-9
supported modes	2-9

W

Wake-on LAN	2-13
wake-up event	3-21
write-back	3-33

