

6A815EPQ

User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

| | |
|--|------|
| 1.1 Features | |
| 1.1.1 Hardware | 1-2 |
| 1.1.2 Software | 1-4 |
| 1.1.3 Attachments | 1-4 |
| 1.2 Motherboard Installation | |
| 1.2.1 Motherboard Map | 1-5 |
| 1.2.2 Motherboard Layout | 1-6 |
| 1.3 Motherboard Connectors | |
| 1.3.1 Front Panel Connector(J7) | 1-8 |
| 1.3.2 Floppy Disk Connector(FDD1) | 1-9 |
| 1.3.3 Hard Disk Connectors(IDE1/IDE2) | 1-9 |
| 1.3.4 ATX 20-pin Power Connector(PW1) | 1-10 |
| 1.3.5 Infrared Connector | 1-10 |
| 1.4 Back Panel Connectors | |
| 1.4.1 PS/2 Mouse/Keyboard CONN. | 1-11 |
| 1.4.2 USB Connectors | 1-11 |
| 1.4.3 VGA Interface Connector | 1-11 |
| 1.5 Serial and Parallel Interface ports | 1-13 |
| 1.6 CPU Installation | |
| 1.6.1 CPU Installation Product(Socket 370) | 1-15 |
| 1.7 Jumper Setting | |
| 1.7.1 CPU Fan Connectors(FAN1/2/3) | 1-16 |
| 1.7.2 BIOS Flash(JP4) | 1-17 |
| 1.7.3 Keyboard wake up Setting(JP7) | 1-17 |
| 1.7.4 CMOS Function Setting(JP6) | 1-17 |
| 1.7.5 CNR Card Setting(J8) | 1-18 |
| 1.7.6 STR LED(LED1) | 1-18 |
| 1.7.7 IrDA Connector(IR) | 1-18 |

Table of Contents

| | |
|------------------------------------|------|
| 1.8 DRAM Installation | |
| 1.8.1 DIMM | 1-19 |
| 1.8.2 How to install a DIMM Module | 1-19 |

2. BIOS Setup

| | |
|-----------------------------------|------|
| 2.1 Main Menu | 2-4 |
| 2.2 Standard CMOS Features | 2-7 |
| 2.3 Advanced BIOS Features | 2-10 |
| 2.4 Advanced Chipset Features | 2-14 |
| 2.5 Integrated Peripherals | 2-17 |
| 2.6 Power Management Setup | 2-23 |
| 2.7 PnP/PCI Configurations | 2-27 |
| 2.8 PC Health Status | 2-31 |
| 2.9 Frequency/Voltage Control | 2-33 |
| 2.10 Load Fail-Safe Defaults | 2-34 |
| 2.11 Load Optimized Defaults | 2-35 |
| 2.12 Set Supervisor/user Password | 2-36 |
| 2.13 Save & Exit Setup | 2-38 |
| 2.14 Exit Without Saving | 2-39 |

3. Driver Installation

| | |
|--|-----|
| 3.1 Auto-run Menu | 3-1 |
| 3.2 Installing Intel INF Driver | 3-2 |
| 3.3 Installing Ultra ATA Driver | 3-4 |
| 3.4 Installing Hardware Monitoring Utility | 3-5 |
| 3.5 Installing Easy Over Clock Driver | 3-6 |