

Chapter 1

1

Introduction

How This Manual is Organized

This manual is divided into the following sections:

Chapter 1 Introduction : Manual information and checklist.

Chapter 2 Features : Information and Specifications concerning this mainboard.

Chapter 3 Installation : Instructions on setting up the board.

The mainboard is a high-performance mainboard based on the advanced PENTIUM™ microprocessor, the PCI Bus and the VIA MVP4 chipset.

The mainboard offers a high degree of flexibility in configuration and is fully IBM PC/AT compatible.

This mainboard provide both power supply solution of ATX type. If user equip with ATX power supply for the system . This board will support more special functions as following. Please follow the description of chapter 3.

A. Touch button : (PANEL1) PWN

Soft-Off by PWR BTTN (Power On/Off) and SUSPEND MODE SWITCHMUTIFUNCTION.

B. Resume by Ring :

To let System wake up and enter DOS OS through Modem during system is power off.

C. Resume by Alarm :

To set up what time to let the system wake up and enter DOS OS drung power off status.

D. Windows 95/98/2000 system Software shutdown (power off) automatically

Note :

Please make sure your system with ATX power supply before you set up the above function.

Package Checklist

Please check that your package is complete . If you discover any item damaged or missing , please contact with your retailer immediately.

- ⌚ The 5VIA73 mainboard.
- ⌚ 1 x UDMA66 ribbon cable.
- ⌚ 1 x VGA with mounting bracket.
- ⌚ 1 x floppy ribbon cable.
- ⌚ 1 x parallel and 2 com port ribbon cable.
- ⌚ 1 x Midi Port and 3 Phone Jack in bracket.
- ⌚ 5VIA73 support software:
 - Flash Memory Write utility to update the FLASH BIOS.
 - Technical Support Form.
- ⌚ This user's Manual

Chapter 2

2

Features


Features of the 5VIA73 Mainboard

- ⌚ VIA MVP4 PCIsset™ chipset
- ⌚ Support either 133~550 MHz PENTIUM™ CPUs with 321pin socket 7.
- ⌚ Support Pentium P54C/P54CS/P55C-MMX
- ⌚ Support Cyrix 6x86, 6x86L, MX, AMD K5, K6, K6-2, K6-3 CPUs
- ⌚ **support AT/ATX Power supply (20 pin) connector.**

- ⌚ **support "Touch Button Wake up" for soft power on/off and suspend mode multifunction.**
- ⌚ **support Windows 95/98 system Software shutdown (power off) automatically**
- ⌚ **support Resume by Ring through Modem.**
- ⌚ **Support Resume by Alarm from System BIOS setting.**
- ⌚ Uses 168-Pin DIMM modules x3 auto banking in multiple configuration up to 640MB.
- ⌚ **Support SDRAM/EDO DRAM Mode DRAM use 3.3 Votage 168-pin DIMMx3.**
- ⌚ Support Onboard Burst/Pipelined burst synchronous L2 Write Back cache. The Cache memory combination could be 512K/1M.
- ⌚ 3 PCI Bus slots, and 1 x 16 bits ISA Bus slots.
- ⌚ All 3 PCI slots support Master mode.
- ⌚ System BIOS support 4 IDE harddisk drivers that don't need device driver for S/W application, the capacity of each harddisk can large than 528MB up to 8.4GB(or more).
- ⌚ PCI Bus master IDE interface on board with two connectors support 4 IDE devices in 2 channel, the PCI IDE Controller supports PIO Mode 0 to Mode 4, Bus master IDE DMA Mode 2 and **Ultra DMA 66MB**
- ⌚ Support PS/2™ mouse Connector.
- ⌚ Support the Universal Serial Bus (U.S.B)

- ⌚ **System BIOS supports LS-120, ZIP driver firmware and Green feature function, Plug and Play Flash ROM.**
- ⌚ **Use switching power supply to support CPU core voltage.**
- ⌚ Support Software Virus Warning in BIOS
- ⌚ Support ACPI functionStatic Electricity Precautions

The 5VIA73 Mainboard layout



Chapter 3

3

Installation

Jumper

Jumper	Refer to page
♦ JBAT1 - Real time Clock RTC clean	12
♦ JTAG1 - TAG RAM Voltage select	12
♦ J2 - CD Line in	12
♦ J8 - BIOS Voltage Select	13
♦ J5, J6, J7 - AMR Control	13
♦ JFAN1 - FAN CONN. for CPU	27
♦ JFAN2 - FAN CONN. for System	27
♦ JWOL1 - LAN Card Wake Up	31

Expansion Slot	Which to pages
♦ 168 pin DIMM Socket	16
♦ Socket 370	17
♦ PCI SLOT 1,2,3 -32bits PCI SLOT	25
♦ ISA SLOT1 - 16bits ISA SLOT	25

Connectors	Refer to page
♦ USB1 - USB Port	25
♦ USB2 - USB Port	25
♦ COM1 - COM 1 serial port	25
♦ COM2 - COM 2 serial port	25
♦ LPT1 - Parallel port	25
♦ FDC1 - FLOPPY connector	25
♦ PS2 - PS/2 Mouse port.	26
♦ CN2 - AT Keyboard port	26
♦ IDE1 - Primary IDE connector	28
♦ IDE2 - Secondary IDE connector	28
♦ JIR1 - IrDA connector	28
♦ PANAL 1 - HDD LED	29
♦ PANAL 1 - Reset Switch	29
♦ PANAL 1 - Speaker Connector	29
♦ PANAL 1 - Power LED	29
♦ PANAL 1 - ATX Power switch	29
♦ CN2 - ATX Power Connector	30
♦ CN3 - AT Power Connector	30
♦ J3 - Audio & Game Port Connector	31

System Installation Setup

Before using your computer, you must finish the following steps:

1. Set jumpers on mainboard
2. Install SDRAM module.
3. Install the Processor.
4. Connect Ribbon Cables, Cabinet Wires, and Power supply.
5. Install Add on Cards.
6. Setup the BIOS software.





Static Electricity Precaution

- ⌚ Keep the mainboard and other system components in their anti-static packaging until you are ready to install them.
- ⌚ Do all preparative work on a static-free surface with the main board components facing up.
- ⌚ Unplug your computer when working on the inside.
- ⌚ Wear an Anti-static wrist strap.
- ⌚ Hold the system components, boards or cards by its edges only. Be careful not to touch any of IC chips, circuitry, contacts or connections, especially gold contacts on the mainboard.

Jumper Settings

Jumpers


Several hardware settings are made through the use of jumper caps to connect jumper pins (Jxx) on the mainboard. See "Map of the mainboard" for the location of the jumpers.

The jumper settings will be described numerically such as [---], [1-2], [2-3] for no connection, connect pins 1 & 2, and connect pins 2 & 3 respectively. Pin 1 for our mainboard is always on top one or on the left when holding the mainboard with the keyboard away from yourself. "P1" is written besides pin 1 on jumper with three pins. The jumpers will also be shown graphically such as  to connect pin 1&2 and  to connect 2&3. Jumpers with two pins will be shown as  for Short (on) and  for Open (off). For manufacturing simplicity it may be sharing pins from other groups. Use the diagrams in this manual instead of following the pin layout on the board. Settings with two jumper numbers require that both jumpers be moved together. To connect the pin, simply place a plastic jumper cap over the two pins as diagrammed.

Real Time Clock (RTC) RAM - JBAT1 :

The CMOS RAM is powered by the onboard button cell battery. To clear the RTC data:

(1) Turn off your computer, (2) Move this jumper to "2-3Pin Clear Data", (3) Move the jumper back to "Default", (4) Turn on your computer, (5) Hold down <Delete> during bootup and enter BIOS setup to re-enter user Preferences.




TAG RAM Voltage Select - JTAG1 :

CD LINE IN - J2 :

The 4-pin connectors enable the system to receive the audio output from the CD-ROM.

BIOS Voltage Select - J8 :

This allows you to select BIOS Voltage setting function.



AMR Contorl - J5, J6, J7 :

This mainboard provides a AMR slot. You may be enabled or disabled according as your sound card's functions:

J5	J6	J7	Description
CLOSE	CLOSE	1-2	AC'97 Function
CLOSE	OPEN	3-4	MC'97 Function
CLOSE	CLOSE	1-2,3-4	AC'97 +MC'97 Function
CLOSE	OPEN	3-4	AMR Function

Note :

You must configure the setting for "Onboard Sound : Disabled" in Chipset Feature Setup and "Onboard Legacy Audio : Disabled" in Integrated Peripherals.
Please insert a sound card to PCI1 slot

System Memory (DIMM Module)

This **5VIA73** main board supports three 168 pins DIMM of 16 MB, 32 MB, 64 MB, 128 MB ,256MB to form a memory size between 16MB to 256MB.

The DRAM can be either 45ns,50ns,or 60ns 3.3v SDRAM,and 3.3v Enhanced Data Output (EDO) RAM.

Install memory in any or all Banks in Combination:


Bank	Memory module
DIMM 1	16MB,32MB,64MB,128MB,128MB
(Bank 0-1)	168 pin,3.3v SDRAM / EDO RAM
DIMM 2	16MB,32MB,64MB,128MB,256MB
(Bank 2-3)	168 pin 3.3v,SDRAM / EDO RAM
DIMM 3	16MB,32MB,64MB,128MB,256MB
(Bank 4-5)	168 pin 3.3v,SDRAM / EDO RAM
	Total System Memory(Max 640 MB)

Note :

- ♦ The DIMM Slot does not support any 5v EDO DIMM module.
- ♦ The DIMM Slot does not support any 5v SDRAM DIMM module.
- ♦ Memory speed setup is required through "Auto Configuration" in BIOS chipset Setup of BIOS SOFTWARE. If several speed memorious are used, You must set Auto Configuration to low. Example If both 50ns, 60ns are used, Please set Auto configuration to 60ns.
- ♦ It's allowed any DIMM module put in any DIMM slot. It's allowed there are different capacity DIMM module in all DIMM slot.



The Dual Inline Memory Module (DIMM) memory module must be 3.3v Extended Data Output (EDO) DRAM or SDRAM. You can identify the type of DIMM module by the illustration below:



168 Pin DRAM DIMM Notch Key Definitions


The notch on the DIMM module will shift between left, center, or right to identify the type and also to prevent the wrong type to be inserted into the DIMM slot on the Mainboard. You must ask your retailer for Specifications before purchasing.

Four clock signals are supported on this mainboard


CPU Installation

The motherboard provides a ZIF socket 7. The CPU that came with the motherboard should have a fan attached to it to prevent over-heating . If this is not the case then purchase a fan before you turn on your system.

To install a CPU , first turn off your system and remove its cover. Locate the ZIF socket and open it by first pulling the lever sideways away from the socket then upwards to a 90-degree right angle. Insert the CPU with the correct orientation shown . The notched corner should point towards the end of the lever. Because the CPU has a corner pin for two of the four corners, the CPU will only fit in the orientation as shown.



JP1 CPU Core Voltage Selection (1-5)



















JP1 CPU Core Voltage Selection (1-5)

Refer to the following table for more CPU core Voltage selection jumper setting:

CPU Voltage	9-10	7-8	5-6	3-4	1-2	Vcore
	OFF	OFF	OFF	OFF	OFF	0
	OFF	OFF	OFF	OFF	ON	2.1
	OFF	OFF	OFF	ON	OFF	2.2
	OFF	OFF	OFF	ON	ON	2.3
	OFF	OFF	ON	OFF	OFF	2.4
	OFF	OFF	ON	OFF	ON	2.5
	OFF	OFF	ON	ON	OFF	2.6
	OFF	OFF	ON	ON	ON	2.7
	OFF	ON	OFF	OFF	OFF	2.8
	OFF	ON	OFF	OFF	ON	2.9
	OFF	ON	OFF	ON	OFF	3.0
	OFF	ON	OFF	ON	ON	3.1
	OFF	ON	ON	OFF	OFF	3.2
	OFF	ON	ON	OFF	ON	3.3
	OFF	ON	ON	ON	OFF	3.4
	OFF	ON	ON	ON	ON	3.5

JP1 CPU Core Voltage Selection (1-5)


Refer to the following table for more CPU core Voltage selection jumper setting:

CPU Voltage	9-10	7-8	5-6	3-4	1-2	Vcore
	ON	ON	ON	ON	ON	2.05
	ON	ON	ON	ON	OFF	2.00
	ON	ON	ON	OFF	ON	1.95
	ON	ON	ON	OFF	OFF	1.90
	ON	ON	OFF	ON	ON	1.85
	ON	ON	OFF	ON	OFF	1.8
	ON	ON	OFF	OFF	ON	1.75
	ON	ON	OFF	OFF	OFF	1.7
	ON	OFF	ON	ON	ON	1.65
	ON	OFF	ON	ON	OFF	1.6
	ON	OFF	ON	OFF	ON	1.55
	ON	OFF	ON	OFF	OFF	1.50
	ON	OFF	OFF	ON	ON	1.45
	ON	OFF	OFF	ON	OFF	1.40
	ON	OFF	OFF	OFF	ON	1.35
	ON	OFF	OFF	OFF	OFF	1.30

JP1 CPU Ratio Selection (6-8)

This Jumper set the frequency ratio between the internal frequency of the CPU and the external frequency (called the bus clock) within the CPU. These must be set together with the above Jumper CPU model ratio bus frequency.

JP1 CPU Ratio Selection (6-8)



CPU Ratio	15-16	13-14	11-12	Ratio
	OFF	ON	ON	2.5
	OFF	ON	OFF	3.0
	OFF	OFF	ON	2.0
	OFF	OFF	OFF	1.5/3.5
	ON	ON	ON	4.5
	ON	ON	OFF	5.0
	ON	OFF	ON	4.0
	ON	OFF	OFF	5.5

CPU	Clock	FSB JP2(1-4)	Ratio JP1(6-8)
AMD-K6-III-450MHz	450MHz	100MHz	x4.5
AMD-K6-III-400MHz	400MHz	100MHz	x4.0
AMD-K6-2-550MHz	550MHz	100MHz	x5.5
AMD-K6-2-500MHz	500MHz	100MHz	x5.0
AMD-K6-2-450MHz	450MHz	100MHz	x4.5
AMD-K6-2-400MHz	400MHz	100MHz	x4.0
AMD-K6-2-350MHz	350MHz	100MHz	x3.5
AMD-K6-2-300MHz	300MHz	100MHz	x3.0
AMD-K6-2-266MHz	250MHz	100MHz	x2.5
AMD-K6-2-380MHz	380MHz	95MHz	x4.0
AMD-K6-2-333MHz	333MHz	95MHz	x3.5
AMD-K6-300MHz	300MHz	66MHz	x4.5
AMD-K6-266MHz	266MHz	66MHz	x4.0
AMD-K6-233MHz	233MHz	66MHz	x3.5
AMD-K6-200MHz	200MHz	66MHz	x3.0
AMD-K6-166MHz	166MHz	66MHz	x2.5
AMD-K5-PR200	200MHz	66MHz	x3.0
AMD-K5-PR166	166MHz	66MHz	x2.5
AMD-K5-PR133	133MHz	66MHz	x1.5
Intel Pentium MMX-233	233MHz	66MHz	x3.5
Intel Pentium MMX-200	200MHz	66MHz	x3.0
Intel Pentium MMX-166	166MHz	66MHz	x2.5
Intel Pentium MMX-150	150MHz	60MHz	x2.5
Intel Pentium-200	200MHz	66MHz	x3.0
Intel Pentium-166	166MHz	66MHz	x2.5
Intel Pentium-150	150MHz	60MHz	x2.5
















CPU	Clock	FSB JP2(1-4)	Ratio JP1(6-8)
Intel Pentium-133	133MHz	66MHz	x2.0
Intel Pentium-120	120MHz	60MHz	x2.0
Cyrix MII PR333	333MHz	83MHz	x3.0
Cyrix MII PR300	300MHz	66MHz	x3.5
Cyrix MII PR266	266MHz	83MHz	x2.5
Cyrix 6x86MX PR233(M2)	233MHz	75MHz	x2.5
Cyrix 6x86MX PR200(M2)	150MHz	75MHz	x2.0
Cyrix 6x86MX PR200(M2)	166MHz	66MHz	x2.5
Cyrix 6x86MX PR166(M2)	133MHz	66MHz	x2.0
Cyrix 6x86MX PR166(M2)	150MHz	60MHz	x2.5
Cyrix 6x86 P200+	150MHz	75MHz	x2.0
Cyrix 6x86 P166+	133MHz	66MHz	x2.0
Cyrix 6x86 P150+	120MHz	60MHz	x2.0
IDT WinChip 2-300	300MHz	100MHz	x2.5
IDT WinChip 2-266	266MHz	100MHz	x5.5
IDT WinChip 2-233	233MHz	66MHz	x3.5
IDT WinChip 2-200	200MHz	66MHz	x3.0
IDT C6-240	240MHz	60MHz	x4.0
IDT C6-225	225MHz	75MHz	x3.0
IDT C6-200	200MHz	66MHz	x3.0
IDT C6-180	180MHz	60MHz	x3.0
IDT C6-240	150MHz	75MHz	x2.0
RISE MP6 (PR266)	200MHz	100MHz	x2.0
RISE MP6 (PR233)	190MHz	95MHz	x2.0
RISE MP6 (PR166)	166MHz	83MHz	x2.0

CPU External (Bus) Frequency Selection -JP2

This Jumper tell the clock generator what frequency to send to the CPU. These allow the selection of the CPUs external frequency (or bus clock). The bus clock times the bus ratio equals the CPUs internal frequency (the advertised CPU speed).

NOTE:

Most of the CPU frequency are locked by the manufacturer.
This motherboard is able to auto-detect the CPU frequency.

JP2	1-2	3-4	5-6	7-8	CPUFSB	PCIFSB
	OFF	OFF	OFF	OFF	60	30
	ON	OFF	OFF	OFF	66.8	33.4
	OFF	ON	OFF	OFF	70	35
	ON	ON	OFF	OFF	75	25
	ON	OFF	ON	OFF	83.3	27.76
	OFF	ON	ON	OFF	95.25	31.75
	ON	ON	ON	OFF	100	33.33
	OFF	OFF	OFF	ON	75	37.5
	ON	OFF	OFF	ON	80	40
	OFF	ON	OFF	ON	83.3	41.65
	ON	ON	OFF	ON	105(103)	35
	OFF	OFF	ON	ON	110(107)	36.67
	ON	OFF	ON	ON	115(112)	38.33
	OFF	ON	ON	ON	120(117)	40
	ON	ON	ON	ON	124(122)	41.33

Clearance Requirements


To maintain proper airflow once the processor is installed on the mainboard, the processor and fan heatsink require certain space clearances. The clearance above the processor must be at least 0.3 inch. The clearance on at least 3 of 4 sides of the processor and fan heatsink must be at least 0.2 inch. All cables (for Floppy drive, Hard drive, CD-ROM, and so on) must be routed clear of the processor and its airspace.

Fan Exhaust

The processor must be kept cool by using a processor with heatsink and fan attached. The temperature of the air filled with the fan/heatsink cannot exceed 45 °C (113 °F). The ambient or room temperature must be below 37 °C (99 °F).

EXTERNAL CONNECTORS

Both Ribbon cable and Connectors on board are with direction sign to avoid that user insert wrong direction. On other hand, the ribbon cables should always be connected with the red stripe on the pin 1 of side of the connector.



1. AT Keyboard port

This connector will compatible with standard at AT size (large DIN) keyboard plugs. You may use a DIN to mini DIN adapter on standard AT keyboards.

2. PS/2 Mouse port

This system will direct IRQ12 to PS/2 mouse.

3. Serial Port COM 1 and COM 2 port

The two serial ports can be used for pointing devices or other serial devices. See "Onboard Serial Port" in chipset Feature Setup of the BIOS SOFTWARE.

4. Parallel Printer port

You can enable the parallel port and choose the IRQ through "Onboard Parallel Port" in Chipset. Feature Setup of the BIOS SOFTWARE.

5. Universal Serial BUS Ports 1 , 2 , 3 & 4


Two USB ports A&B are available for connecting USB devices.

6. Floppy drive connector

This connector supports the provided floppy drive ribbon cable. After connecting the single end to the board, connect the two plus on the other end to the floppy drives.

7. FAN1 , FAN2 CPU Cooling Fan (JFAN1,2)

These connectors support cooling fans of 500mAmp (6Watt) or less. Orientate the fans so that the heat sink fins allow airflow to go across the onboard heat sink(s) instead of the expansion slots. Depending on the fan manufacturer, the wiring and plug may be different. The red wire should be positive, while the black should be ground. Connect the fan's plug to the board taking into consideration the polarity of this connector.



NOTE :

The "Rotation" signal is to be used only by a specially designed fan with rotation signal.

WARNING :

The CPU and/or motherboard will overheat if there is no air flowing across the CPU and onboard heatsinks. Damage may occur to the motherboard and/or the CPU fan if these pins are incorrectly used. These are not jumpers, do not place jumper caps over these pins.

8. Primary / Secondary IDE connectors (Two 40-pin Blocks)

These connectors support the provided IDE hard disk ribbon cable. After connecting the single end to the board, connect the two plugs at the other end to your hard disk no space(s) . If you install two hard disks, you must configure the second drive to Slave mode by setting its jumper settings. BIOS now supports SCSI device or IDE CD-ROM boot up (see "HDD Sequence SCSI/IDE First" & "Boot Sequence" in the BIOS Features Setup of the BIOS SOFTWARE) (Pin 20 is removed to prevent inserting in the wrong orientation when using ribbon cables with pin 20 plugged).


Tip :

You may configure two hard disks to be both Masters using one ribbon cable on the primary IDE connector. You may install one operating system on an IDE drive and another on a SCSI drive and select right one the through BIOS Feature Setup.


9. IrDA / Fast IR-Compliant infrared module connector - JIR1

This connector supports the optional wireless transmitting and receiving infrared module. This module mounts to a small opening on system cases that support this feature. You must also configure the setting through "UART2 Use Infrared" in Chipset Feature Setup to select whether UART2 is directed for use with COM2 or IrDA. Use the five pins as shown on the Back View and connect a ribbon cable from the module to the motherboard according to the pin definitions.

JIR1 IR Connector	
Pin	Description
1	+5V
2	NC
3	IRRXX
4	Ground
5	IRTX



10. PANEL 1



a. IDE activity LED (HD-LED)

This connector supplies power to the cabinet's IDE activity LED. Read and write activity by devices connected to the Primary or Secondary IDE connectors will cause the LED to light up.

b. PowerLED Lead (PE_BN)

The system power LED lights when the system's power is on.

c. SMI Suspend Switch Lead (SMI)

This allows the user to manually place the system into a suspend mode or "Green" mode where systematic activity will be instantly decreased to save electricity and expand the life of certain components when the system is not in use. This 2-pin connector (see the figure below) connects to the case-mounted suspend switch. If you do not have a switch for the connector, you may use the "Turbo Switch" since it does not have a function. SMI is activated when it detects a short to open moment and therefore leaving it shorted will not cause any problems. It may require one or two pushes depending on the position of the switch. Wake-up can be controlled by settings in the BIOS but the keyboard will always allow wake-up (the SMI lead cannot wake-up the system). If you want to use this connector, "Suspend Switch" in the Power Management Setup of the BIOS SOFTWARE section should be on the default setting of Enable

d. Reset Switch Lead (RST)

This 2-pin connector connects to the case-mounted reset switch for rebooting your computer without having to turn off your power switch. This is a preferred method of rebooting in order to prolong the life of the system's power supply.

e. **System Power LED (PANEL)**

The system power LED lights when the system's power is on (same as above Power LED).

11. **ATX/AT Power Supply Connector (pin block) - CN2/CN3**

This connector connects to a ATX power supply. The plug from the power supply will only insert in one orientation because of the different hole sizes. Find the proper orientation and push down firmly making sure that the pins are aligned.

IMPORTANT:

Make sure that the ATX power supply can take at least 10mAmp load on the 5Volt standby lead (5VSB). You may experience difficulty in powering on your system without this.

Pin	Description	Pin	Description
1	3.3V	2	3.3V
3	GND	4	5V
5	GND	6	5V
7	GND	8	PW-OK
9	5VSB	10	12V
11	3.3V	12	-12V
13	GND	14	PS-ON
15	GND	16	GND
17	GND	18	-5V
19	5V	20	5V


Pin	Description	Pin	Description
1	Power Good	7	Ground
2	+5V DC	8	Ground
3	+12V DC	9	-5V DC
4	-12V DC	10	+5V DC
5	Ground	11	+5V DC
6	Ground	12	+5V DC

12. Audio & Game Connector Port :J3

This connector is provided for audio unput and ouput signals. Using a ribbon cable, you can connect a audio connector.

13. Wake Up On LAN : JWOL1

This connector connects LAN cards and a Wake On LAN output. When the system is in soft-off mode LAN activity will power on the system.



Date : / /

Guarantee Sheet/Technical Fault Report

M/B Model No.: _____ Vender

Serial No. : _____

Date of Purchasing: _____

Hardware Configuration Used :

CPU	
RAM	
Video Card	
Hard Drive	
Other Card	

Diagnostic Software Used :

Fault Description :

Technical Support :

WWW : www.acorp.com.tw

FAE : fae@acorp.com.tw