

694XT

User's Manual Version 1.1

The information presented in this publication has been carefully prepared to ensure reliability ; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	2
1.1.2 Software	4
1.1.3 Attachments	4
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	5
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(PANEL1)	7
1.3.2 Floppy Disk Connector(FDD1)	8
1.3.3 Hard Disk Connectors(IDE1/IDE2)	8
1.3.4 ATX 20-pin Power Connector(PW1/PW2)	9
1.3.5 Infrared Connector(IR)	9
1.4 Back Panel Connectors	
1.4.1 MS1 Mouse/Keyboard CONN.	10
1.4.2 USB Connectors(USB1/USB2)	10
1.5 Serial and Parallel Interface ports	11
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	13
1.6.2 CPU Clock Setting(JCK1~JCK4,JC1,JC3)	14
1.7 Jumper Setting	
1.7.1 CPU Fan Connectors(FAN1/2)	15
1.7.2 Wake-On-Lan Header(WOL1)	16
1.7.3 AMR Function Selection(J1)	16
1.7.4 CMOS Function Selection(JBAT1)	16
1.7.5 CPU Type Selection(JC1~JC2,JC4~JC5)	17

Table of Contents

1.8 DRAM Installation	
1.8.1 DIMM	18
1.8.2 How to install a DIMM Module	18
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	19
1.9.2 Audio & Connectors(Audio)	19

2. BIOS Setup

2.1 Main Menu	23
2.2 Standard CMOS Features	26
2.3 Advanced BIOS Features	29
2.4 Advanced Chipset Features	33
2.5 Integrated Peripherals	38
2.6 Power Management Setup	43
2.7 PnP/PCI Configurations	49
2.8 PC Health Status	53
2.9 Frequency/Voltage Control	54
2.10 Load Fail-Safe Defaults	56
2.11 Load Optimized Defaults	57
2.12 Set Supervisor/user Password	58
2.13 Save & Exit Setup	60
2.14 Exit Without Saving	61