

6VIA85X

User's Manual Version 1.0

The information presented in this publication has been carefully prepared to ensure reliability ; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	1-2
1.1.2 Software	1-4
1.1.3 Attachments	1-4
1.2 Motherboard Installation	
1.2.1 Motherboard Map	1-5
1.2.2 Motherboard Layout	1-6
1.3 Motherboard Connectors	
1.3.1 Front Panel Connector(PANEL1)	1-8
1.3.2 Floppy Disk Connector(FDD1)	1-9
1.3.3 Hard Disk Connectors(IDE1/IDE2)	1-9
1.3.4 ATX 20-pin Power Connectors(PW1/PW2)	1-10
1.3.5 Infrared Connector(IR)	1-10
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	1-11
1.4.2 USB Connectors(USB1/USB2)	1-11
1.5 Serial and Parallel Interface ports	1-12
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	1-14
1.6.2 CPU Clock Selection(JCK1~JCK4,JC1,JC3)	1-15
1.7 Jumper Setting	
1.7.1 CPU Fan Connectors(FAN1/2)	1-16
1.7.2 Wake-On-LAN Header(WOL1)	1-17
1.7.3 AMR Set Function(J1)	1-17
1.7.4 CMOS Function Selection(JBAT1)	1-17
1.7.5 CPU Type Select(JC1~JC2,JC4~JC5)	1-18
1.8 DRAM Installation	
1.8.1 DIMM	1-19
1.8.2 How to install a DIMM Module	1-19

Table of Contents

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-19
2.6 Power Management Setup	2-23
2.7 PnP/PCI Configurations	2-29
2.8 PC Health Status	2-33
2.9 Frequency/Voltage Control	2-34
2.10 Load Fail-Safe Defaults	2-35
2.11 Load Optimized Defaults	2-36
2.12 Set Supervisor/user Password	2-37
2.13 Save & Exit Setup	2-39
2.14 Exit Without Saving	2-40

3. Driver Installation

3.1 Main Menu	3-1
3.2 Installing VIA 4 in 1 Driver	3-2

Before you proceed:

Take note of the following precautions before you install device on motherboard:

1. Please check up motherboard connector & jumper (see the figure below). The 6VIA85X motherboard doesn't support **AMR set function** on page 1-17, so don't use this function.
2. Because 6VIA85X M/B doesn't support AMR slot, please modify BIOS item on page 2-17 (see the below).

“Onchip sound” & “Onchip Modem”

The choices: Disabled(default), Auto.

