

6VIA89

User's Manual Version 1.2

The information presented in this publication has been written carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Chapter 1	Introduction	1
	How this manual is organized	1
	Package checklist	2
Chapter 2	Features	3
	Features of the mainboard	4
Chapter 3	Installation	5
	The 6VIA89 Mainboard Layout	7
	System Installation Setups	8
	Static Electricity Precaution	8
	Jumper Settings	9
	System Memory (DIMM modules)	11
	DIMM Memory Installation	12
	CPU Installation	14
	Clearance Requirements	18
	Fan Exhaust	18
	External Connectors	19

Note:

If there is any change in the content please refer to our website. Regarding the BIOS setting & Driver installation, refer the web site please.([www. acorp.com.tw](http://www.acorp.com.tw))