

7KMA

User's Manual Version 1.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Athlon is a trademark of AMD Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	2
1.1.2 Software	4
1.1.3 Attachments	4
1.2 Motherboard Installation	
1.2.1 Layout of Motherboard	5
1.3 Motherboard Connectors	
1.3.1 Front Panel Connectors(J1)	7
1.3.2 Floppy Disk Connector(FDD1)	8
1.3.3 Hard Disk Connectors(IDE1/IDE2)	8
1.3.4 ATX 20-pin Power Connector(PW1)	9
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	10
1.4.2 USB Connectors(RJ45+USB)	10
1.4.3 VGA Interface Connector(VGA1)	11
1.5 Serial and Parallel Interface ports	12
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 462)	14
1.6.2 CPU Clock Setting(SW1)	15
1.7 Jumper Setting	
1.7.1 CPU Fan Connector(FAN1/2/3)	16
1.7.2 Wake-On-Modem Header(WOM1)	17
1.7.3 Wake-On-LAN Header(WOL1)	17
1.7.4 AMR Code Select(JP1)	18
1.7.5 CMOS Function Selection(JP2)	18
1.8 DRAM Installation	
1.8.1 DIMM	19
1.8.2 How to install a DIMM Module	19
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	20

Table of Contents

2. BIOS Setup

2.1 Main Menu	24
2.2 Standard CMOS Features	27
2.3 Advanced BIOS Features	30
2.4 Advanced Chipset Features	34
2.5 Integrated Peripherals	38
2.6 Power Management Setup	43
2.7 PnP/PCI Configurations	48
2.8 PC Health Status	52
2.9 Frequency/Voltage Control	53
2.10 Load Fail-Safe Defaults	54
2.11 Load Optimized Defaults	55
2.12 Set Supervisor/user Password	56
2.13 Save & Exit Setup	58
2.14 Exit Without Saving	59