

# **7KT266AL**

## **User's Manual Version 1.0**

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket462 is a trademark of AMD Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

**Trademarks and/or registered trademarks are the properties of their respective owners.**

---

## Table of Contents

### Introduction

## 1. Motherboard Description

1.1 Features	
1.1.1 Hardware	1-2
1.1.2 Software	1-4
1.1.3 Attachments	1-4
1.2 Motherboard Connectors	
1.2.1 Front Panel Connector(J5)	1-6
1.2.2 Floppy Disk Connector(FDD)	1-7
1.2.3 Hard Disk Connectors(IDE1/IDE2)	1-7
1.2.4 ATX 20-pin Power Connector(ATX)	1-8
1.2.5 Infrared Connector	1-8
1.3 Back Panel Connectors	
1.3.1 PS/2 Mouse/Keyboard CONN.	1-9
1.3.2 USB Connectors(USB1 & USB2)	1-9
1.4 Serial and Parallel Interface ports	1-11
1.5 CPU Installation	
1.5.1 CPU Installation Procedure(Socket 462)	1-12
1.5.2 CPU Clock Frequency Setting(JP4)	1-13
1.5.3 CPU Ratio Selector(SW1)	1-14
1.6 Jumper Setting	
1.6.1 CPU/Fan Connectors(CPU FAN/FAN1/2)	1-15
1.6.2 Wake-On-Modem Header(WOM)	1-16
1.6.3 Wake-On-LAN Header(WOL)	1-16
1.6.4 Keyboard Power on Function(JP1)	1-16
1.6.5 CMOS Function Setting(JBAT)	1-17
1.7 Installation Memory	
1.7.1 SDRAM & DDR Module	1-17

## Table of Contents

1.8 Audio Subsystem	
1.8.1 CD-Audio-IN Connectors(CDIN1/CDIN2)	1-19
1.8.2 Line-in/out, MIC Header(AUDIO)	1-19
<b>2. BIOS Setup</b>	
2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-19
2.6 Power Management Setup	2-25
2.7 PnP/PCI Configurations	2-29
2.8 Miscellaneous Control	2-33
2.9 Load Optimized Defaults	2-34
2.10 Load Standard Defaults	2-35
2.11 Set Supervisor/user Password	2-36
2.12 Save & Exit Setup	2-38
2.13 Exit Without Saving	2-39
<b>3. Driver Installation</b>	
3.1 Main Menu	3-1
3.2 Installing VIA 4 in 1 Driver	3-2
3.3 Installing Audio Driver	3-3
<b>a. Appendix</b>	