

AP5TC

User's Guide

Printed in Taiwan

PART NO.: 49.87907.001

DOC. NO. : AP5TC-1-E9801A

AP5TC

Mainboard

User's Guide

Document Number : AP5TC-1-E9801A
Model and Revision : For AP5TC revision 1.xx
Manual Version : English, revision A
Release Date : Jan 9, 1998

More help for latest information:

Taiwan ***<http://www.aopen.com.tw>***
USA ***<http://www.aopen-usa.com>***
 <http://www.aopenamerica.com>
Europe ***<http://www.aopen.nl>***

Copyright

Copyright © 1998 by this company. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, manual or otherwise, without the prior written permission of this company.

Disclaimer

This company makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Intel and Pentium are registered trademarks of Intel Corporation.

XT/AT is a registered trademark of International Business Machines Corporation.

AMI is a registered trademark of American Megatrends Inc.

AWARD is a registered trademark of Award Software Inc.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Organization

Chapter 1, **Overview**, covers the introduction and specifications of the system board.

Chapter 2, **Hardware Installation**, describes hardware jumpers, connectors and memory configuration. There are user friendly drawings to locate jumper and connector.

Chapter 3, **AWARD BIOS**, explains the system BIOS and tells how to configure the system by setting the BIOS parameters.

Appendix A, **Frequently Asked Question**, collects most frequently asked question of this product.

Appendix B, **Troubleshooting Guide**, includes first aid information you need if you meet trouble, the WWW address and worldwide service telephone/fax are also included.

Appendix C, **Jumper Table Summary**, gives you a tabular summary of the jumper settings discussed in Chapter 2.

Conventions

The following conventions are used in this manual:

Text entered by user,
default settings,
recommended selections

Represent text input by the user,
default settings and recommended
selections

<Enter>, <Tab>,<Ctl>, <Alt>,
<Ins>, , etc

Represent the actual keys that you
have to press on the keyboard.



Note:

Gives bits and pieces of additional
information related to the current topic.



Warning:

Alerts you to any damage that might
result from doing or not doing specific
actions.



Caution:

Suggests precautionary measures to
avoid potential hardware or software
problems.



Important:

Reminds you to take specific action
relevant to the accomplishment of the
procedure at hand.



Tip:

Tells how to accomplish a procedure
with minimum steps through little
shortcuts.

Contents

CHAPTER 1 OVERVIEW

1.1 SPECIFICATIONS	3
1.2 SUSPEND TO HARD DRIVE	5
1.3 CPU THERMAL PROTECTION	8
1.4 PCI SOUND CARD CONNECTOR.....	9

CHAPTER 2 HARDWARE INSTALLATION

2.1 JUMPERS AND CONNECTOR LOCATIONS	2
2.2 JUMPERS	4
2.2.1 Setting the CPU Voltage	5
2.2.2 Selecting the CPU Frequency	8
2.2.3 Clearing the CMOS	12
2.3 CONNECTORS	13
2.3.1 Power Cable.....	13
2.3.2 CPU Fan.....	14
2.3.3 PS/2 Mouse.....	14
2.3.4 Serial Devices (COM1/COM2)	15
2.3.5 USB Device (optional)	15
2.3.6 Floppy Drive	16
2.3.7 Printer.....	16
2.3.8 IDE Hard Disk and CD ROM.....	17
2.3.9 Hard Disk LED	18
2.3.10 Panel Connector.....	19
2.3.11 Keyboard.....	20
2.3.12 IrDA Connector	21
2.3.13 SB-LINK	22
2.4 INSTALLING THE SYSTEM MEMORY.....	23

CHAPTER 3 AWARD BIOS

3.1 ENTERING THE AWARD BIOS SETUP MENU	2
3.2 STANDARD CMOS SETUP	3
3.3 BIOS FEATURES SETUP.....	6
3.4 CHIPSET FEATURES SETUP.....	11
3.5 POWER MANAGEMENT SETUP.....	17

3.6 PNP/PCI CONFIGURATION SETUP	22
3.7 LOAD SETUP DEFAULTS	26
3.8 LOAD TURBO DEFAULTS.....	26
3.9 INTEGRATED PERIPHERALS.....	27
3.10 PASSWORD SETTING	32
3.11 IDE HDD AUTO DETECTION	32
3.12 SAVE & EXIT SETUP.....	33
3.13 EXIT WITHOUT SAVING	33
3.14 NCR SCSI BIOS AND DRIVERS	33
3.15 BIOS FLASH UTILITY.....	34

APPENDIX A FREQUENTLY ASKED QUESTION

APPENDIX B TROUBLESHOOTING

APPENDIX C JUMPER TABLE SUMMARY