


Quick Connector and Jumper Reference

CN1: WOL (Wake-on-LAN) Conn.




CN4: Creative's SB-Link connector (links AWE64D with PCI Bus Mastering)

CN5: Infrared connector



CN6: Front panel connector set



CN15: FANII connector


CN16: CPU temperature jumper

FAN1/FAN2: System/CPU cooling fan connector



JP1: Factory default

JP2: On board Audio jumper
1~2 : Enabled
2~3 : Disabled



SeePU (Jumper free CPU installation) setting table

CPU Type	CPU Speed		
	External Clock	Frequency Ratio	Internal Clock
Pentium II processor	66	3.5	233
		4	266
		4.5	300
		5	333

JP3: Clear CMOS data jumper

1~2 : Normal (default)
2~3 : Clear CMOS data

JP4: Power-on by keyboard jumper

1~2 : Disabled (default)
2~3 : Enabled

JP8: On board VGA jumper

1~2 : Disabled
2~3 : Enabled