

3. Carefully push the SIMM down and back into the socket until the retaining clips of the socket snap, holding the SIMM in place. The holes in the SIMM should match the pins on the socket's retaining clips.

To remove the SIMM/s, pull the retaining latch on both ends of the socket and reverse the procedure above.

---

## Cache Memory

---

The 486-GIO-VT can accept cache memory of 64, 128 or 256KB.

→ **NOTE :** Be sure to use the correct chips for the amount of cache memory you want to add. You must install both the correct Cache and Tag SRAM.  
Alter RAM type is always the same as Tag RAM.

## Installing Cache Memory

---

→ **NOTE :** Always observe static electricity precautions. See "Handling Precautions" at the beginning of this manual.

If you do not have the confidence to make the installation, better consult a service technician for assistance.

1. Locate the cache memory on the mainboard.  
See Figure 3-1 again.
2. Be guided by the Cache SRAM settings depending on your desired SRAM configuration.

Correct orientation of the chips is necessary for the cache to operate properly. Normally, the chips have either a curved notch or a dot. This marker on the chip must be matched to the marker on the socket for correct alignment.