











Jumper Setting for Printer Mode

	<i>Print (Default)</i>	<i>EPP/SPP</i>	<i>EPP/ECP</i>	<i>EXT2FDD</i>
<i>JW3</i>				
<i>JW4</i>				

Jumper Setting for ECP Mode DMA Channel

	<i>DMA 1 (Default)</i>	<i>DMA 3</i>
<i>JW5</i>		
<i>JW6</i>	