

Table of Contents

Chapter 1 Overview

Package Checklist.....	2
The KL-6011 Mainboard	3
Main Features	4
Advanced Features	5
1). Enhanced Performance Features.....	5
2). Intelligent Features	6
ISMP™ (Intelligent System Management & Protection)	6
PC '97 Compliant	7
ACPI Ready	8
DMI (Desktop Management Interface)	8
Intel LANDesk® Client Manager (optional)	9
Infrared Connections	10
Highly Convenient Integrated I/O Connectors	10

Chapter 2 Installation Procedures

Mainboard Layout	12
1). Set System Jumpers.....	13
Jumpers	13
Clear Password: CPW	14
Flash EPROM Type Selection: EP1, EP2.....	14
2). Install RAM Modules.....	15
SDRAM	15
RAM Module Configuration.....	16
Install DIMMs.....	17
Remove DIMMs	17
3). Install the CPU	18
Retention Mechanism Kit	18
CPU Module Installation	19
CPU to Bus Frequency Ratio:	
FREQ1, FREQ2, FREQ3, FREQ4	24
Intel Pentium II CPUs	24
Frequency.....	24
4). Install Expansion Cards.....	25
5). Connector Cables and Power Supply	27
Serial Port Connectors: COM1, COM2	27

CPU Fan Connector: FAN1	27
System Case Fan Connector: FAN2.....	28
Floppy Diskette Drive Connector: FLOPPY.....	28
Front Panel Block Connector: F_PNL	29
Infrared Connector: IR	30
PS/2 Keyboard and Mouse Connector: KB, MS	30
ATX Power Connector: POWER.....	31
IDE HDD Device Connectors: PRIMARY, SECONDARY	31
Printer Connector: PRINTER	32
Universal Serial Bus Connectors: USB1, USB2	32
Chassis Open Alarm Connector: CHASSIS	33

Chapter 3 BIOS Setup

Main Setup	35
Advanced Setup.....	36
Advanced CMOS Setup	37
Advanced Chipset Setup	42
Power Management Setup.....	46
Plug and Play Setup	50
Peripheral Setup.....	53
Hardware Monitor Setup.....	55
Security Setup.....	56
Exit Setup	57

Appendix A Software Utilities

PIIX Bus Master IDE Driver	59
USB Supplement Software	59
Intel INF Update Software	59
BIOS Flash Software.....	59
Intel LDCM® (LANDesk Client Manager) Software (optional).....	60
Desktop Management Interface (DMI) Software	60
Anti-Virus Tool (optional)	60