

## Installation Procedures


The PT-2006 has several user-adjustable jumpers on the board that allow you to configure your system to suit your requirements. This chapter contains information on the various jumper settings on your mainboard.

To set up your computer, you should follow these installation steps:

- Step 1 -  
Set system jumpers
- Step 2 -  
Install RAM modules
- Step 3 -  
Install the CPU
- Step 4 -  
Install expansion cards
- Step 5 -  
Connect cables and power supply
- Step 6 -  
Set up BIOS feature (Please read Chapter Three.)

**CAUTION** : If you use an electric driver to install this mainboard on your chassis, please wear a static wrist strap and the recommended electric driver torque is from 5.0 to 8.0 kg/cm to avoid damaging chips' pins.


Mainboard Layout




## 1). Set System Jumpers

### *Jumpers*

Jumpers are used to select the operation modes for your system. Some jumpers on the board have three metal pins with each pin representing a different function. To set a jumper, a black cap containing metal contacts is placed over the jumper pins according to the required configuration. A jumper is said to be shorted when the black cap has been placed on one or two of its pins. The types of jumpers used in this manual are shown below:



Jumper cap is shown as above





Jumpers in a Block

**NOTE :** Users are not encouraged to change the jumper settings not listed in this manual. Changing the jumper settings improperly may adversely affect system performance.


### *Power Supply Type Selection: PWR1*

This jumper allows you to select your power supply type: an AT power supply or remote power supply.




***Clear Password: CPS***

This jumper allows you to set the password configuration to Enabled or Disabled. You may need to enable this jumper if you forget your password.



***Flash ROM Type Selection: EP1, EP2, EP3***

These jumpers allow you to select the flash ROM type.



## 2). Install System RAM Modules

### DRAM and SDRAM

The working space of the computer is the Random Access Memory (RAM). The system cannot act upon data unless it is loaded into RAM. When more memory is added, the working memory of the computer is larger, thereby increasing total performance.

The PT-2006's RAM is comprised of four industry standard 72-pin Single In-line Memory Modules (SIMMs) and one Dual In-line Memory Modules (DIMMs). Each SIMM socket supports from 4 to 64MB FPM (Fast Page Mode) and high-speed EDO (Extended Data Out) DRAM. Each DIMM socket is able to support up to 64MB EDO DRAM or lightning-fast SDRAM.

SDRAM is an advanced new memory technology that boosts overall system performance with its ability to synchronize all operations with the processor clock signal. This makes the implementation of control interfaces easier, and speeds up column access time. SDRAM features an on-chip burst counter that can be utilized to increment column addresses for very fast burst access, which means that SDRAM allows new memory access to be initiated before the preceding access has been finished.

Before making DRAM upgrades you should verify the type and speed of the RAM currently installed from your dealer. Installing mixtures of RAM types other than those described in this manual will have unpredictable results.

## RAM Module Configuration

SIMMs and DIMMs in Bank 0 and Bank 1 can be installed in many combinations. Some of them are listed in the following table.

(Unit : MB)

TOTAL MEMORY	SIMM (Bank 0)	SIMM (Bank 1)	DIM (Bank 1)
8	4 & 4		
			8
16	8 & 8		
			16
32	16 & 16		
			32
64	32 & 32		
			64*
128	64 & 64		
			64*


<b>NOTE :</b> * RAM module of this size was not available for testing at press time. Also, the DIMM and SIMMs are not recommended install on the mainboard at the same time
---

## Install SIMMs

Complete the following procedures to install SIMMs:

**CAUTION :** Always turn the system power off before installing or removing any device; and see “Handling Precautions” at the start of this manual.

1. Locate the SIMM slots on the mainboard. (See figure below.)



**NOTE :** SIMMs in each bank must be of the same type; and the BIOS automatically configures the memory size.

2. Carefully fit a SIMM at a 45 degree angle into each empty socket to be populated. All the SIMMs must face the same direction.
3. Swing each SIMM into its upright, locked position.  
When locking a SIMM in place, push on each end of the SIMM - do not push in the middle, as shown above.


## Remove SIMMs

To remove the SIMMs, pull the retaining latch on both ends of the socket and reverse the procedure above.

## Install DIMMs

Complete the following procedures to install DIMMs:

1. Locate the DIMM slots on the mainboard. (See figure below.)



2. Install the DIMM straight down into the DIMM slot with both hands.
3. The clips of the slot will close up to hold the DIMM in place when the DIMM touches the slot's bottom.

## Remove DIMMs

Press the clips with both hands to remove the DIMM.



## Cache Memory


Cache memory access is very fast compared to main memory access. The cache holds data for imminent use. Since cache memory is five to more than ten times faster than main memory, the CPU's access time is reduced, giving you better system performance.

The PT-2006 comes with onboard 256/512KB synchronous 3V Pipeline Burst SRAMs and one cache SRAM module slot which allows you to expand the cache RAM size. The specification of the cache SRAM module requires Intel Coast. Standard version 3.X, such as FIC PB512K-3.0.

Please note that for 256K secondary cache, M2 and M3 should be mounted with 32Kx32 Pipeline Burst SRAM. (Please refer to your dealer for the 512KB cache upgraded and the appropriate SRAM type).

### Install Cache SRAM Module

1. Locate the C\_SLOT on the mainboard. (See figure below.)




2. Insert the cache SRAM module straight down onto the slot.



## 256/512KB Cache SRAM (Onboard)

**NOTE :** Use the correct chips for the amount of cache memory you want to add. Install both the correct Cache and Tag SRAM.



### 256KB




### 512KB



## 512KB Cache RAM (Onboard and SRAM Module)




## 256/512KB Cache RAMh (SRAM Module)



### 3). Install the CPU

The CPU module resides in the Zero Insertion Force (ZIF) socket on the mainboard.



**CAUTION :**

1. Always turn the system power off before installing or removing any device.
2. Always observe static electricity precautions.  
See "Handling Precautions" at the start of this manual.
3. Inserting the CPU chip incorrectly may damage the chip.


To install the CPU, do the following:

1. Lift the lever on the side of the CPU socket.
2. Handle the chip by its edges and try not to touch any of the pins.
3. Place the CPU in the socket. The chip has a notch to correctly orientate the chip. Align the notch with pin one of the socket. Pin one is located in the blank triangular area. Do not force the chip. The CPU should slide easily into the socket.
4. Swing the lever to the down position to lock the CPU in place.
5. See the following sections for information on the CPU jumpers settings.

### CPU External Clock (BUS)

#### Frequency: CLK1, CLK2

The table below shows the jumper settings for the different CPU speed configurations.



CLK1	CLK2
1	1
66 MHz	66 MHz
1	1
60 MHz	60 MHz
1	1
55 MHz	55 MHz
1	1
50 MHz	50 MHz

### CPU to Bus Frequency Ratio:FREQ1 and FREQ2


These two jumpers are used in combination to decide the ratio of internal frequency of the CPU to bus clock.

FREQ1	FREQ2
1	1
3 x Ext.	3 x Ext.
1	1
2.5 x Ext.	2.5 x Ext.
1	1
2 x Ext.	2 x Ext.
1	1
1.5 x Ext.	1.5 x Ext.



Intel Pentium CPUs

Frequency

CPU Speed	External (CPU/CLK)	CLK1	CLK2	CPU Clock Rate		
				Internal	FREQ1	FREQ2
200 MHz	66 MHz			3 x Ext.		
166 MHz	66 MHz			2.5 x Ext.		
150 MHz	60 MHz			2.5 x Ext.		
133 MHz	66 MHz			2 x Ext.		
120 MHz	60 MHz			2 x Ext.		
100 MHz	66 MHz			1.5 x Ext.		
90 MHz	60 MHz			1.5 x Ext.		
75 MHz	50 MHz			1.5 x Ext.		



## Voltage



AMD-K5 CPUs

Frequency


Model Name	CPU Speed	External (CPU/CLK)	CLK1	CLK2	CPU Clock Rate		
					Internal	FREQ1	FREQ2
K5-PR166 *	133 MHz	66 MHz			2 x Ext.		
K5-PR150 *	120 MHz	60 MHz			2 x Ext.		
K5-PR133 *	100 MHz	66 MHz			1.5 x Ext.		
K5-PR120 *	90 MHz	60 MHz			1.5 x Ext.		
K5-PR100 *	100 MHz	66 MHz			1.5 x Ext.		
K5-PR90	90 MHz	60 MHz			FREQ1 1.5 x Ext.		
K5-PR75	75 MHz	50 MHz			FREQ2 1.5 x Ext.		

**NOTE :** \* This CPU had not yet been tested when this manual was printed.




## Voltage


VR1 VR2




Core : 3.4V-3.6V  
IO : Same  
AMD-K5 - B




Core : 3.3V  
IO : Same  
AMD-K5 - C, F



Core : 2.9V  
IO : 3.3V  
AMD-K5 - H




Core : 2.8V  
IO : 3.3V  
AMD-K5 - J



Core : 2.5V  
IO : 3.3V  
AMD-K5 - K


### AMD-K5 CPU Top Side Marking



V (Identifier for Operation Voltage) :

B  
C  
F  
H  
J  
K


Please refer to  
the left-hand-side table




Cyrix 6x86 CPUs  
*Frequency*

Model	CPU Speed (MHz)	External (CPU/CLK) (MHz)	Clock Generator						Internal	CPU Clock Rate		
			IMI 652			ICS 9147				FREQ1	FREQ2	FREQ3
			CLK1	CLK2	CLK3	CLK1	CLK2	CLK3				
M2 <sup>★</sup>	233	66							3.5 x			
M2 <sup>★</sup>	200	66							3 x			
M2 <sup>★</sup>	166	66							2.5 x			
M2 <sup>★</sup>	150	60							2.5 x			
6x86-PR166+ 6x86L-PR166+	133	66							2 x			
6x86-PR150+ 6x86L-PR150+	120	60							2 x			
6x86-PR133+ 6x86L-PR133+	110	55							2 x			


**NOTE :** \* This CPU had not been tested when this manual was printed.




## Voltage



Core : 3.4V-3.6V  
IO : Same  
Cryix 6x86-028




Core : 3.3V  
IO : Same  
Cryix 6x86-016



Core : 2.5V  
IO : 3.3V  
Cryix 6x86L \*

## Cyrix 6x86 CPU Top Side Marking

6x86-PR166<sup>+</sup>GP  
133 MHz  
3.52V (028)




IBM 6x86 CPUs

Frequency


Model	CPU Speed (MHz)	External (CPU/CLK) (MHz)	Clock Generator						Internal	CPU Clock Rate		
			IMI 652			ICS 9147				FREQ1	FREQ2	FREQ3
			CLK1	CLK2	CLK3	CLK1	CLK2	CLK3				
M2 <sup>★</sup>	233	66							3.5 x			
M2 <sup>★</sup>	200	66							3 x			
M2 <sup>★</sup>	166	66							2.5 x			
M2 <sup>★</sup>	150	60							2.5 x			
6x86-PR166+ 6x86L-PR166+	133	66							2 x			
6x86-PR150+ 6x86L-PR150+	120	60							2 x			
6x86-PR133+ 6x86L-PR133+	110	55							2 x			

NOTE : \* This CPU had not been tested when this manual was printed.




## Voltage


VR1 VR2



Core : 3.4V-3.6V  
IO : Same  
Cryix 6x86-028




Core : 3.3V  
IO : Same  
Cyrix 6x86-016




Core : 2.5V  
IO : 3.3V  
Cyrix 6x86L \*

## IBM 6x86 CPU Top Side Marking

6x86-PR166<sup>+</sup>GP  
133 MHz  
3.52V (028)



## 4). Install Expansion Cards



Your PT-2006 features three 16-bit ISA Bus and four 32-bit PCI Bus expansion slots.


This section describes how to connect an expansion card to one of your system's expansion slots. Expansion cards are printed circuit boards that, when connected to the mainboard, increase the capabilities of your system. For example, expansion cards can provide video and sound capabilities.

### **CAUTION :**

1. Always turn the system power off before installing or removing any device.
2. Always observe static electricity precautions.  
See "Handling Precautions" at the start of this manual.

To install an expansion card, do the following:


1. Remove the chassis cover and select an empty expansion slot.
2. Remove the corresponding slot cover from the chassis. Unscrew the mounting screw that secures the slot cover and pull the slot cover out from the chassis. Keep the slot cover mounting screw nearby.
3. Holding the edge of the peripheral card, carefully align the edge connector with the expansion slot.
4. Push the card firmly into the slot. Push down on one end of the expansion card, then the other. Use this "rocking" motion until the add-in card is firmly seated inside the slot.
5. Secure the board with the mounting screw removed in Step 2.  
Make sure that the card has been placed evenly and completely into the expansion slot.



## 5). Connect Cables and Power Supply


### ***Keyboard Connector: AT\_KB***

The cable of your 101-key enhanced keyboard or 106-key Windows 95 keyboard is plugged into this connector.





### ***Serial Port Connectors: COM1, COM2***

These two connectors allow you to connect with your devices that take serial ports, such as a serial mouse or a modem. Usually, it is recommended to connect your serial mouse to COM1 and your fax/modem to COM2. Because COM2 and IR utilizes the same IRQ, COM2 will not work if an IR device is connected to the IR connector.




***CPU Fan Connector: FAN***

This connector is linked to the CPU fan for cooling the processor temperature.



***Floppy Diskette Drive Connector: FLOPPY***


This connector provides the connection with your floppy disk drive.



***Front Panel Block Connector: F\_PNL***




This block connector concludes : PW\_LED, KB\_LOCK, TB\_LED, SP\_SW, SPK, SP\_LED, IDE\_LED, RPW\_SW, and RST connectors.



Item	Connector	Pin Type	Feature
A	PW_LED	2-pin male	indicates the system power status
B	KB_LOCK	2-pin male	allows the keyboard to access the system
C	TB_LED	2-pin male	indicates the system speed is in normal or turbo speed
D	SP_SW	2-pin male	Suspend Mode switch
E	SP_LED	2-pin male	indicates the system into Suspend Mode when LED lit
F	SPK	4-pin male	connects to speaker
G	IDE_LED	2-pin male	indicates the IDE HDD I/O access LED lit
H	RPW_SW	2-pin male	Remote Power switch
I	RST	2-pin male	allows you to reset the system


***Infrared Connector: IR***

This connector supports the connection to your IR device. The IR port uses the same IRQ as COM2 port, therefore you need to adjust this BIOS option when an IR device is installed.




***Standard Power Supply Connector: POWER***

This 12-pin block connector is used for connecting to the standard 5V power supply. In the picture below, notice that, in most cases, there are two marks “P8” and “P9” on the surface of the connector. You have to insert the “P8” plug into the “P8” section of the connector, and so forth for “P9”. Two black wires must be in the middle.




***IDE HDD Device Connectors: PRIMARY, SECONDARY***

These two connectors are used for your IDE hard disks. If you have one IDE hard disk, connect it to the PRIMARY connector using the IDE HDD flat cable provided with the mainboard. The BIOS auto detection sets it to be a “Primary Master” disk. If you want to install another IDE hard disk or CD-ROM, please use the SECONDARY connector.




***Printer Connector: PRINTER***

This connector is featured onboard for the connection with your printer.




***Remote Power Supply Connector: RPW\_CON***

This 3-pin male connector allows you to enable (or disable) the system power if the RPW\_SW is on (or off).



***Universal Serial Bus Connectors: USB1, USB2***

These two connectors link with USB peripheral devices via an optional USB riser card.



**NOTE :** If the USB riser card is installed and the USB feature is enabled. The PCI4 Slot will be utilized by the USB function; in such a case, no add-on card is allowed at PCI4 Slot, since PCI4 Slot is dedicated to the USB function when the USB function is enabled.