

Chapter 1 Overview

Package Checklist..... 2
Main Features 3
Advanced Features 5
 1). Enhanced Performance Features..... 5
 2). Intelligent Features 7
 PC '97 Compliant 8
 ACPI Ready 9
 DMI (Desktop Management Interface) 10
 Serial Infrared (SIR) Connections..... 11
 Highly Convenient Integrated I/O Connectors..... 12

Chapter 2 Installation Procedures

Mainboard Layout 13
1). Set System Jumpers..... 14
 Jumpers 15
 Clear Password: CPW 16
 Flash EPROM Type Selection: EP1, EP2..... 16
 Power Type Selection: PWR1 17
2). Install System RAM Modules 18
 DRAM and SDRAM..... 18
 RAM Module Configuration..... 19
 Install SIMMs 20
 Remove SIMMs 20
 Install DIMMs..... 21
 Remove DIMMs 21
 Cache Memory..... 22
 Install Cache SRAM Module 22
 Onboard Cache SRAM (256KB/512KB)..... 22
3). Install the CPUs 23
 CPU External Clock (Bus) Frequency:
 CLK1, CLK2, CLK3 24
 CPU to Bus Frequency Ratio:
 FREQ1, FREQ2, FREQ3 25
 Intel Pentium CPUs..... 26
 Frequency..... 26
 Voltage..... 27

AMD-K5/K6 CPUs.....	28
Frequency.....	28
Voltage.....	29
Cyrix 6x86 CPUs.....	30
Frequency.....	30
Voltage.....	31
IBM 6x86 CPUs.....	32
Frequency.....	32
Voltage.....	33
4). Install Expansion Cards.....	34
5). Connector Cables and Power Supply.....	36
Serial Port Connectors: COM1, COM2.....	36
CPU Fan Connector: FAN.....	36
System Case Fan Connector: EXT_FAN.....	37
Front Panel Block Connector: F_PNL.....	38
Infrared Connector: IR.....	39
PS/2 Keyboard Connector: PS2_KB.....	39
PS/2 Mouse Connector: PS2_MS.....	40
ATX Power Connector: ATX_PWR.....	40
Standard Power Connector: AT_PWR.....	41
IDE HDD Device Connectors: PRIMARY, SECONDARY.....	41
Printer Connector: PRINTER.....	42
Remote Power Supply Connector: RPW_CON.....	42
Universal Serial Bus Connector: USB0, USB1.....	43

Chapter 3 AMI BIOS Setup

Main Setup.....	45
Advanced Setup.....	46
Advanced CMOS Setup.....	47
Advanced Chipset Setup.....	51
Power Management Setup.....	54
Plug and Play Setup.....	58
Peripheral Setup.....	61
Security Setup.....	64
Exit Setup.....	66

Appendix A Software Utilities

DMI Utility.....	67
System Requirements	67
Edit BIOS DMI Information	67
Installing DMI Wizard	68
Starting DMI Wizard	68
Main Screen Actions	68
IDE Utility.....	70

Appendix B BIOS Update Instruction

Flash Process	71
---------------------	----

Appendix C ICW/PhaseLink Clock Generator

CPU External Clock (Bus) Frequency:	
CLK1, CLK2, CLK3	73
Intel Pentium CPUs.....	74
Frequency.....	74
AMD-K5/K6 CPUs.....	75
Frequency.....	75
Cyrix 6x86 CPUs.....	77
Frequency.....	77
IBM 6x86 CPUs.....	77
Frequency.....	77

This Page Intentionally Left Blank