

Kapitel 1 Montage

CMOS löschen: SW1-5	2
Kennwort löschen: SW1-6	2
Auswahl des Flash-ROM: EP1, EP2	3
DIMM-Frequenz und Systemfrequenz: FREQ1, FREQ2.....	3
Prozessorfrequenz: SW-1, SW-2, SW-3, SW-4	4

Kapitel 2 BIOS-Einrichtung

CMOS Setup Utility	5
Standard CMOS Setup.....	6
Festplattenkonfiguration	6
Software Turbo Speed	7
BIOS Features Setup	7
Chipset Features Setup	11
Power Management Setup	15
PNP/PCI-Konfiguration	19
Load BIOS Defaults.....	22
Load Setup Defaults	22
Integrated Peripherals.....	23
Kennworte (Supervisor/User Password)	27
 Autom. Festplattenerkennung (IDE HDD Auto Detection)	28
Save and Exit Setup.....	29
Exit without Saving	29