



IDE HDD Device Connectors: PRIMARY and SECONDARY

These two 40-pin block connectors are used for your IDE hard disk drives. If you have one IDE hard disk, connect it to the PRIMARY connector. The BIOS automatic detection sets it to be a "Primary Master" hard disk drive. If you want to install another IDE hard disk drive or CD-ROM, please use the SECONDARY connector. If two hard disk drives are connected to the PRIMARY connector via the same flat ribbon cable, one of them is the Master Drive, the other is the Slave Drive. You may need to configure some jumpers for the Slave Drive; refer to the respective HDD manual for details.



ATX Power Connector: POWER

This 20-pin male block connector is used for connecting to your ATX power supply.



Printer Block Connector: PRINTER

This 26-pin male block connector is attached to your printer via the printer cable.

