

## ***Table of Contents***

### **Chapter 1    Installation Procedures**

Clear Password: CPW .....	2
Flash EPROM Type Selection: EP1, EP2.....	2
CPU to Bus Frequency Ratio:	
FREQ1, FREQ2, FREQ3, FREQ4.....	3
Intel Pentium II CPUs .....	3
Frequency.....	3

### **Chapter 2    BIOS Setup**

Main Setup .....	5
Advanced Setup .....	6
Advanced CMOS Setup.....	6
Advanced Chipset Setup.....	10
Power Management Setup .....	13
Plug and Play Setup .....	17
Peripheral Setup.....	19
Hardware Monitor Setup.....	23
Security Setup.....	24
Exit Setup .....	25