


# A POST Messages

The following table lists the Power On Self Test (POST) messages, possible causes, and solutions.

<b>Message</b>	<b>Possible Cause</b>	<b>Solution</b>
NO DISKETTE CONTROLLER	Disk controller not found.	Change the Configuration.
DISKETTE DRIVE RESET FAILED	Disk adapter has failed or is improperly configured.	Check the disk adapter.
DISKETTE DRIVE A FAILURE	Drive A failed or is missing.	Check the A drive.
DISKETTE DRIVE B FAILURE	Drive B failed or is missing.	Check the B drive.
DISKETTE READ FAILURE; STRIKE F1 TO RETRY BOOT	Disk is not formatted or is defective.	Replace the diskette with a formatted diskette and retry.
DISPLAY ADAPTER FAILED USING ALTERNATE	The color/monochrome switch is not set correctly, or the primary video adapter failed.	Change the switch to the correct setting, or check the primary video adapter.
ERRORS FOUND; DISK X FAILED INITIALIZATION	Hard disk configuration information is incorrect.	Rerun SETUP and enter the correct hard disk information.
ERRORS FOUND; INCORRECT CONFIGURATION INFORMATION; MEMORY SIZE MISCOMPARE	The size of the base or the expansion memory, does not agree with configuration information.	Enter correct memory size and rerun SETUP procedure.

<b>Message</b>	<b>Possible Cause</b>	<b>Solution</b>
FIXED DISK CONFIGURATION FAILURE	The specified configuration is not supported.	Correct the hard disk configuration.
FIXED DISK CONTROLLER FAILURE	The controller card has failed.	Replace controller card.
FIXED DISK X FAILURE (where X =0 or 1)	The hard disk crashed.	Press F1 to reboot or rerun SETUP. If this does not work, replace hard disk.
HARD READ FAILURE- STRIKE F1 TO RETRY BOOT	The hard disk failed.	Press F1 to reboot or rerun Setup. If this does not work, replace hard disk.
FDD CONTROLLER FAILURE	Diskette controller failed.	Replace controller card.
FDD A IS NOT INSTALLED	Cannot find diskette controller for drive A.	Install or replace controller card.
FDD B IS NOT INSTALLED	Cannot find diskette controller for drive B.	Install or replace controller card.
KEYBOARD CLOCK LINE FAILURE or KEYBOARD DATA LINE FAILURE	Keyboard logic failed.	Make sure the keyboard cable is connected correctly.
KEYBOARD STUCK KEY FAILURE	A key is jammed or was held down during boot.	Make sure the keys are not jammed or dirty.
REAL TIME CLOCK FAILURE	The real-time clock logic failed.	Check battery and replace, if necessary
TIME-OF-DAY NOT SET- RUN SETUP PROGRAM	The real-time clock time-of-day is not running.	Run SETUP utility.
BIOS XXXX ROM BAD CHECKSUM (where XXXX=C8000 to E0000)	The optional ROM checksum is bad.	Replace add-on card.

Message	Possible Cause	Solution
DISKETTE READ FAILURE, or NOT A BOOT DISKETTE, or NO BOOT DEVICE AVAILABLE	Hard/floppy disk failed or is not bootable.	Replace the diskette with a bootable diskette and retry.
DECREASING AVAILABLE MEMORY, or MEMORY FAILURE AT AAAAAAAAAA READ XXXX EXPECTING YYYY (where AAAAAAAAAA = failing address, XXXX=data read, and YYYY=data written)	The memory data integrity failed.	Check contact points between memory modules and system board. Replace memory modules if necessary.



**Click here to continue  
to the next chapter.....**

