CPU Clock Jumper JK1-JK4 (VT8225N)

CLK 2	JK1	JK2	JK3	JK4
100 MHz	1-2	2-3	1-2	2-3
80 MHz	1-2	1-2	2-3	2-3
66.6 MHz	2-3	2-3	1-2	2-3
50 MHz	2-3	1-2	2-3	2-3
40 MHz	1-2	1-2	2-3	1-2
33.3 MHz	2-3	2-3	1-2	1-2
25 MHz	2-3	1-2	2-3	1-2

Table 2-4. CPU Clock Jumper Selection JK1-JK4 (VT8225N)

Connectors

The connectors allow the mainboard to connect electronically with other parts of the system. Some connectors have two pins, others have four or five pins. Some malfunction problems encountered with your system may be caused by loose or improper connections. Ensure that all connections are in place and firmly attached.