

UMC :

U5S/U5SD/U5SLV -

(U5SX-SUPERXX, U5SD-SUPERXX, U5SLV-SUPERXX*);

Cyrix :

Cx486DX/DX2/DX4 -

(Cx486DX-XXGP, Cx486DX-VXXGP*,

Cx486DX2-XXGP, Cx486DX2-VXXGP*, Cx486DX4-100*);

5x86 -

(5x86-100*, 5x86-120*)

	JC1	JC2	JC3	JC4	JC5	RNA	RNC	RNI
U5SD								
U5S U5SLV								
Cx486DX Cx486DX2								
Cx486DX4 5x86								

* When using this processor, please refer to page 2-11 for more information about jumper setting.

