

ADDENDUM

The following affects **p. 6, 7 and 16** of the Trinity KT-A S2390B Manual Rev1.00.

1-J. USB Header (J2)*

Certain computer chassis allow for USB port connections. This board provides a USB header should you decide to set up an external USB connector. Check with your chassis vendor for details.

*Please be sure that your chassis supports external USB ports before using this feature.

The following replaced the "Where can I get USB cables for my motherboard?" question and answer on **p. 27** of the Trinity KT-A S2390B Manual Rev1.00.

Frequently Asked Questions

Q: Where can I get accessories for my motherboard?*

A: You can purchase accessories from **<http://www.etyan.com>**

*Please be sure your chassis supports external USB ports before using the USB feature. Check with your chassis vendor for details.