Table of Contents

Chapter 1 Overview

Package Checklist 2
Main Features 2
Advanced Features 3
1). Enhanced Performance Features 3
2). Intelligent Features 4
PC '97 Compliant 5
ACPI Ready 5
DMI (Desktop Management Interface) 6
Infrared Connections 7
Universail Serial Bus (USB) Functionality 8

Chapter 2 Installation Procedures

Mainboard Layout 10
1). Set System Jumpers 11
Jumpers 11
Clear Password: CPS 12
Flash EPROM Type Selection: EP1, EP2 12
2). Install RAM Modules 13
DRAM Memory 13
RAM Module Configuration 14
Install SIMMs 16
Remove SIMMs 16
3). Install the CPU 17
Retention Mechanism Kit 17
CPU Module Installation 18
CPU External Clock (Bus) Frequency:
CLK1, CLK2 23
CPU to Bus Frequency Ratio:
FREQ1, FREQ2, FREQ3, FREQ4 23
Intel Pentium II CPUs 24
4). Install Expansion Cards 25
5). Connector Cables and Power Supply 27
Keyboard Connector: AT_KB 27
Serial Port Connectors: COM1, COM2 27
CPU Fan Connector: FAN1 28
Floppy Diskette Drive Connector: FLOPPY 28

Front Panel Block Connector: F_PNL 29
IDE HDD Device Connectors: PRIMARY, SECONDARY 30
Infrared Connector: IR 30
PS/2 Mouse Connector: MS_CON 31
Standard Power Connector: POWER 31
Printer Connector: PRINTER 32
Remote Power Connector: RPW_CON 32
Universal Serial Bus Connector: USB1, USB2 33
System Fan Connector: FAN2 34

Chapter 3 AMI BIOS Setup

Main Setup 36
Hard Disk Configurations 36
Advanced Setup 38
Advanced CMOS Setup 39
Advanced Chipset Setup 44
Power Management Setup 48
Plug and Play Setup 51
Peripheral Setup 54
Security Setup 57
Exit Setup 58

Appendix A DMI Utility

System Requirements 59
Editing BIOS DMI Information 59
Installing DMI Wizard 60
Starting DMI Wizard 60
Main Screen Actions 60

Appendix B BIOS Update Instruction

Flash Process 63