Table of Contents

Chapter 1 Installation Procedures

Clear CMOS: SW1-5 2
Clear Password: SW1-6 2
Flash EPROM Type Selection: EP1, EP2 3
CPU Internal Frequency: SW1-1, SW1-2, SW1-3, SW1-4 4

Chapter 2 BIOS Setup

CMOS Setup Utility 5
Standard CMOS Setup 6
    Hard Disk Configurations 6
    Software Turbo Speed 7
BIOS Features Setup 7
Chipset Features Setup 9
Power Management Setup 12
PNP/PCI Configuration 16
Load BIOS Defaults 17
Load Setup Defaults 17
Integrated Peripherals 17
Supervisor/User Password 22
IDE HDD Auto Detection 23
Save and Exit Setup 24
Exit without Saving 24

This Page Intentionally Left Blank