

CONNECTOR	PIN OUTS	SIGNAL NAME
J15 Speaker Connector	1 2 3 4	Speaker signal NC Ground +5V
J16 Keylock and Power LED Connector	1 2 3, 5 4	Power signal Spare Ground Keylock
J17 * Green Power Supply Connector	1 2	Enable/Disable power supply outlet Ground
CN9 HDD IDE Connector	1 2, 19, 22, 24, 26, 30, 40 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 20, 21, 29, 34 23 25 27 28 31 32 33 35 36 37 38 39	Reset hard disk Ground HDD7 HDD8 HDD6 HDD9 HDD5 HDD10 HDD4 HDD11 HDD3 HDD12 HDD2 HDD13 HDD1 HDD14 HDD0 HDD15 NC HDD I/O write HDD I/O read IOCHRDY HDD address latch IRQ14 IOCS16 HDD A1 HDD A0 HDD A2 HDD chip select 0 HDD chip select 1 HDD active

* Insert two pin connector wire from Green Power Supply into Connector J17.

Table 2-5. Connector Pin Definitions