

JUMPER	PIN DEFINITION
J2	External, Internal Battery Select 1-2 External battery 2-3 Internal battery
J4	Display Type Select Open Mono/EGA/VGA (default) Close Color
J7	Password Clear (Award/AMI BIOS Select) 1-2 Award BIOS 2-3 AMI BIOS
JC6	80486SX/P23S/P4S/CX486S PQFP Select Short Disable on-board Open Enable
JCX1	CPU Type Select Short CX486S Open Intel S-series CPU
JKB1, JKB2, JKB3, JKB4, JX3	Internal/External Keyboard Select 1-2 External keyboard 2-3 Internal keyboard
JX1	CPU Clock Select 1-2 1 X 2-3 2 X
JX2, J8	1-2 IRQ15 2-3 -SMI

Table 2-2. Jumper Definitions