

## **Table of Contents**

### **Chapter 1 Overview**

Package Checklist .....	1
The CL31-A Mainboard .....	2
Main Features .....	3
Advanced Features .....	5
Intel LANDesk® Client Manager (optional) .....	5

### **Chapter 2 Installation Procedures**

1). Set System Jumpers .....	8
Mainboard Layout .....	9
Clear Password: CPW .....	11
CMOS Clear: CMOS_CLR .....	11
Flash ROM Type Select: EP1, EP2 .....	12
Keyboard Power-On Select: KB_PWN .....	12
2). Install RAM Modules .....	13
SDRAM .....	13
RAM Module Configuration .....	13
Install DIMMs .....	14
Remove DIMMs .....	14
3). Install the Central Processing Unit (CPU) .....	15
4). Install Expansion Cards .....	16
5). Connector Cables and Power Supply .....	17
Serial Port Connectors: COM1, COM2 .....	17
PS/2 Keyboard and Mouse Connector: KB and MS .....	17
Printer Connector: LPT1 .....	18
Universal Serial Bus Connectors: USB .....	18
Audio Port Connectors: LINE-OUT, LINE-IN, MIC .....	19
Joystick/MIDI Connector: GAME .....	19
CPU Fan Connector: FAN .....	20
Chassis Intrusion Alarm Connector: CHASSIS .....	20
System Case Fan Connector: CHA_FAN1, CHA_FAN2 .....	21
Infrared Connector: IR .....	21
Floppy Diskette Drive Connector: FDD .....	22
PCI Add-on Audio Card Connector: SB_LINK .....	22
IDE HDD Device Connectors: PRIMARY, SECONDARY .....	23
ATX Power Connector: ATX_PWR .....	24
Remote Wake-Up Connector: RWU .....	25

CD-ROM Drive Audio-out Connector: CD_IN.....	25
Front Panel Block Connector: F_PNL.....	26
Power Connection Procedures .....	27
Powering Off the Computer.....	27

### **Chapter 3 Setting BIOS Feature**

Advanced Configuration & Power Interface (ACPI) .....	29
Main CMOS Setup.....	29
Load Defaults .....	29
Standard CMOS Setup .....	31
Software Turbo Speed .....	33
BIOS Features Setup.....	34
Chipset Features Setup.....	37
Power Management Setup.....	40
PNP and PCI Configuration Setup .....	44
Load BIOS Defaults .....	46
Load Setup Defaults.....	46
Integrated Peripherals .....	47
Supervisor Password and User Password.....	51
IDE HDD Auto Detection.....	52
Save and Exit Setup .....	53
Exit Without Saving.....	53
BIOS Flash Software.....	54
Update BIOS File.....	54

### **Chapter 4 Software Utilities**

Starting Installation.....	57
Virus Detection Agent.....	57
IDE Bus Master .....	59
Installation.....	59
Patch for Chipset.....	60
Installation .....	60
Adobe Acrobat Reader .....	61
Browse CD .....	61
Install Audio Driver .....	61
First AID.....	61
LANDesk Client Manager CD (optional).....	62
Specification Overview .....	62
Two Options of LDCM Setup.....	63