

Chapter 1 Overview

Package Checklist	1-1
The CP11/CP11Z/CP11B Mainboard	1-3
Main Features	1-4
Intelligent Properties	1-6
ACPI Ready	1-7

Chapter 2 Installation Procedures

1). Set System Switches/Jumpers	2-2
Quick Reference	2-3
Mainboard Layout	2-7
Clear CMOS: SW1-5	2-9
Clear Password: SW1_6	2-9
Keyboard and Mouse Power-On Feature: KB_PWN	2-10
System Bus Frequency Select: FS1, FS2	2-10
2). Install RAM Modules	2-11
RAM Module Configuration	2-11
Install and Remove DIMMs	2-12
3). Install the CPU	2-13
CPU Internal Frequency Select: SW-1/-2/-3/-4	2-14
4). Install Expansion Cards	2-14
5). Connect Devices	2-15
Floppy Diskette Drive Connector: FLOPPY	2-16
IDE HDD Device Connectors: PRIMARY, SECONDARY ..	2-16
ATX Power Connector: POWER	2-17
PCI Audio Card Connector: SB_LINK	2-17
CPU Fan Connector: CPU_FAN	2-18
System Case Fan Connector: CHS_FAN	2-18
Wake-On-LAN Connector: WOL	2-19
Infrared Connector: IR	2-19
Front Panel Block Connector	2-20
Serial Port Connectors: COM1, COM2	2-21
Printer Connector: LPT	2-21
PS/2 Keyboard and Mouse Connector: KB, MS	2-22
Universal Serial Bus Connectors: USB0, USB1, USB3	2-22

Chapter 3 BIOS Setup

CP11 BIOS Setup	3-1
CMOS Setup Utility	3-1
Standard CMOS Setup	3-2
Hard Disk Configurations	3-2
Software Turbo Speed	3-3
BIOS Features Setup	3-3
Chipset Features Setup	3-6
Power Management Setup	3-10
PNP/PCI Configuration	3-14
Load BIOS Defaults	3-16
Load Setup Defaults	3-16
Integrated Peripherals	3-17
Supervisor/User Password	3-22
IDE HDD Auto Detection	3-22
Save and Exit Setup	3-22
Exit without Saving	3-22
CP11B/CP11Z BIOS Setup	3-23
Main Setup	3-23
Advanced Setup	3-24
Security Setup	3-25
Exit Setup	3-26
Award BIOS Setup	3-27
CMOS Setup Utility	3-27
Standard CMOS Setup	3-27
Hard Disk Configurations	3-28
Software Turbo Speed	3-28
BIOS Features Setup	3-29
Chipset Features Setup	3-32
Power Management Setup	3-35
PNP/PCI Configuration	3-39
Load BIOS Defaults	3-40
Load Setup Defaults	3-41
Integrated Peripherals	3-41
Supervisor/User Password	3-46

IDE HDD Auto Detection	3-46
Save and Exit Setup	3-46
Exit without Saving	3-46

Chapter 4 FAQs

General FAQs	4-1
BIOS FAQs	4-5
Windows 98 FAQs	4-7
Windows 95 FAQs	4-8
Intel CPU FAQs	4-9

This Page Left Blank for Note