

Chapter 1 Overview

Mainboard Layout	1-2
System Specifications	1-3
Features Highlight	1-5
Add-on Features for VGA in Intel 810/E	1-5
Add-on Features for Audio	1-6
AMR and AC'97 CODEC Controller	1-6
Modem Ring On	1-7
SB-Link Sideband Signals	1-7
Ultra DMA 66 Cable (optional)	1-7
ACPI Ready	1-8
FIC Unique Innovation for Users (NOVUS) -	
Enhanced Mainboard Features and System Support	1-8

Chapter 2 Installation Procedures

QUICK REFERENCE	2-2
CPU Installation	2-7
Socket 370	2-7
SLOT1	2-8
System Memory Installation	2-9
DIMM Type, Size, Parity Supported	2-9
Expansion Cards Installation	2-10
Mainboard Layout	2-12
System Jumpers	2-14
CMOS Clearance Function: JP8	2-15
Audio CODEC Enable: JP9	2-15
CPU Socket Type Select: JP2, JP10	2-16
BIOS Top Block Lock Select: JP3	2-16
Reboot on Timeout: JP1	2-16
BIOS Setting CPU Ratio: JP4	2-17
Connectors	2-17
Floppy Diskette Drive Connector: Floppy	2-17
IDE HDD Device Connectors: IDE1, IDE2	2-18
PCI Add-On Audio Card Connector: SB-LINK	2-18
ATX Power Connector: PW1	2-19
CPU Fan Connector: CPU-FAN	2-19

System Case Fan Connector: CHS-FAN	2-20
Infrared Connector: IR1	2-20
CD Audio-Out Connector: CD1, CD2	2-21
Power Fan Connector: PWR-FAN	2-21
Front Panel Block Connector: FIC1	2-22
Video Graphics Accelerator Connector: VGA	2-23
PS/2 Keyboard and Mouse Connector: KBMS1	2-23
Universal Serial Bus Connectors: USB	2-24
Printer Connector: LPT1	2-24
Serial Port Connectors: COM1, COM2	2-25
Joystick/MIDI Connector: GAME	2-25
Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN	2-26
 Chapter 3 BIOS Setup	
BIOS Configuration Setup	3-2
 Chapter 4 FAQs	
General FAQs	4-1
BIOS FAQs	4-3
Windows 98/98 SE FAQs	4-5
Windows 95 FAQs	4-6