

Chapter 5

WINDOWS 98/NT

Overview

This chapter provides information about Windows 98/NT installation procedure.

To install the SCSI controller driver during Windows NT 4.x installation:

1. Boot the system with the Windows NT 4.x setup diskette #1.
2. Insert setup diskette#2 when prompted and press <Enter>.
3. Press<Enter> again when prompted.
4. Insert setup diskette#3 when prompted and press <Enter>.
5. Select Custom Setup in the Windows NT Setup screen.
6. Choose S to specify an additional device.
7. Choose Other in the list of supported adapters displayed and press <Enter>
8. When prompted for the manufacturer's supplied hardware support disk, insert your DOS-Formatted NT/95 Drivers diskette into the floppy disk drive and press <Enter>.
9. Select the **Adaptec AHA-294xV2/295xV2/AIC-789x PCI Ultra 2 SCSI controller** (NT 4.0).

To install the update utility for Windows 98:

1. Insert the CD-Title provided.
2. The CD-Title will autorun.
3. Click on **INF Update Utility**.
4. This will allow your Windows 98 to recognize the Intel 440GX chipset.